

Supplementary Table 1. The frequency of shooting explants (%) from internodal stems and pulvini of petiole explants cultured on the shoot induction medium with BAP and IBA combinations.

PGRs (mg/L)		Internodal stem		Pulvinus of the petiole	
BAP	IBA	Transverse TCL	Longitudinal TCL	Transverse TCL	Longitudinal TCL
0	0	0	0	0	0
0.25	0	42.5	47.5	42.5	52.5
0.5	0	100	100	100	100
0.75	0	100	100	100	100
1.0	0	100	100	100	100
0	0.25	0	0	0	0
0.25	0.25	0	0	0	0
0.5	0.25	100	100	100	100
0.75	0.25	100	100	100	100
1.0	0.25	100	100	100	100
0	0.5	0	0	0	0
0.25	0.5	0	0	0	0
0.5	0.5	0	0	0	0
0.75	0.5	100	100	100	100
1.0	0.5	100	100	100	100
0	0.75	0	0	0	0
0.25	0.75	0	0	0	0
0.5	0.75	0	0	0	0
0.75	0.75	0	0	0	0
1.0	0.75	100	100	100	100

PGRs: Plant growth regulators; TCL: Thin cell layer; Measurements were taken after eight weeks of culture.